

## Parts List — UP5052

| Part Number | Description                                                          | Config Step        | Qty |
|-------------|----------------------------------------------------------------------|--------------------|-----|
| 250875      | MANUAL, OPERATORS                                                    | Configuration Type | 1   |
| 480770      | BDL, DISTRIBUTION - ULTRAPRO II - 80 RUN - 10 ZONE - TRIPLE PRODUCT  | Tank Size          | 1   |
| 412303      | BDL, STRAP - C/W SIDE RELEASE BUCKLE - STAGE 2                       | Tank Size          | 160 |
| 412670      | BDL, DELIVERY WING HOSE HOLDER - SHORT - STAGE 2                     | Tank Size          | 6   |
| 412671      | BDL, DELIVERY WING HOSE HOLDER - MEDIUM - STAGE 2                    | Tank Size          | 12  |
| 412672      | BDL, DELIVERY WING HOSE HOLDER - LONG - STAGE 2                      | Tank Size          | 2   |
| 410102      | BDL, BAGLIFTER - UPII350/360 - 530 - BASE LEVEL - STAGE 1            | Baglift            | 1   |
| 410104      | CTN, HYD - EXT. KIT - BAGLIFT - UPII 530 BU - STAGE 2                | Baglift            | 1   |
| 414005      | BDL, ULTRAPRO II - 550 BU - 10 ZONE - WIDE M                         | Tank Configuration | 1   |
| 270225      | SCALE, DIGITAL - HANDHELD                                            | Tank Configuration | 1   |
| 451144-1    | BDL, SEEDBDL, SEEDMASTER, REMOTE TANK MONITOR - STAGE 2              | Tank Configuration | 1   |
| 412140-3    | ASSY, CANOLA ROLLER CARTRIDGE - UPII - 8 RUN - STAGE 2               | Tank Configuration | 10  |
| 412103-3    | ASSY, STANDARD ROLLER CARTRIDGE - UPII - 8 RUN - W/ CLAMPS - STAGE 2 | Tank Configuration | 20  |